

P7690

Sol-Mate® Touch Keyhole Light Operation Manual

Thank you for purchasing the P7690 Sol-Mate® Touch Keyhole Light. Please read all instructions prior to use. Proper use and care of this item will allow years of productive use.

It's as simple as Touch, Light and See! Make it easier and safer to unlock your door at night by illuminating your keyhole with the solar powered touch keyhole light. Place the light above the keyhole on your entry door, or use it on your shed, greenhouse, or garage door. With its innovative "touch-on" technology, you simply touch to activate and the light will stay on for approximately 15 seconds so you can get in safely and quickly.

Installation:

1. Determine the mounting position by temporarily placing the unit on the door so that the LED on the bottom of the unit will illuminate the keyhole. Leave enough room above the mounting position to allow the unit to be slid on and off of the mounting plate. This should be about the same height as the unit. Be sure the mounted unit will not interfere with the safe mechanical operation of the door and will not be struck by door hardware or outer doors such as a screened door. Be sure the solar panel (blue-black color) is oriented towards sunlight and is not shaded by door hardware etc. TIP: The unit does not need to be in a vertical line with the keyhole to function. If you need to mount the unit off to the side slightly to accommodate clearances, the light beam will still illuminate the keyhole. You can test the illumination before mounting to be sure.
2. Slide unit off the mounting plate by applying slight pressure to the notch cut-out on the bottom of the mounting plate.
3. Attach the mounting plate to the position you determined above. Ensure the wider portion of the mounting plate with the two "wings" is oriented down and that the narrow tapered portion is oriented up. Use mounting screws or strong double-sided tape to affix.
4. Slide the unit down onto the mounting plate, starting at the top, until the unit snaps into place.

Operation:

The unit may need solar charging before it is ready for use. Allow the unit to charge in sunlight.

To activate the LED lamp, simply touch the flat area below the solar panel. The LED will illuminate for approximately 10 – 15 seconds allowing you to find the keyhole and gain entry. TIP: If you do not receive sufficient sunlight in the mounting location to recharge the unit, you may temporarily remove the unit from the mounting plate and place it in direct sunlight with the solar panel oriented towards the sun. When finished charging the unit replace it onto the mounting plate for use.

**P3 INTERNATIONAL CORPORATION
LIMITED WARRANTY**

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION

TECHNICAL SUPPORT

Tel: 212-741-7289

Fax: 212-741-2288

Email: techsupport@p3international.com

Rev. 1110