

P7815
Solar Animal Chaser

Congratulations on your purchase of the 7815 Solar Animal Chaser. Please read these operating instructions thoroughly before use. It is important for proper use of the product.

The Solar Animal Chaser provides a convenient, effective and humane way to deter cats, dogs, and even raccoons from your garden, yard and lawn without harm. This product utilizes a sophisticated PIR (passive infrared) detection system to monitor a large area up to an approximate distance of 23 ft. When an animal enters the area covered by the infrared sensor, the Solar Animal Chaser produces an ultrasonic sound at a frequency of about 23 kHz that is very unpleasant to animals but inaudible to the human ear. In addition to the noise the unit emits, the Solar Animal Chaser also emits an intense strobe light to further ward off unwanted animals. There is no need to change the batteries on this product for the Solar Animal Chaser operates on solar power.

WARNING:

- ! Turn off the Solar Animal Chaser if your pet is playing in the protected area. !
- ! Do not immerse the unit in water or any other liquid. !
- ! Do not modify or tamper the unit or its internal components. Covering or painting over the front speaker grill can damage the unit and cause it to malfunction. !
- ! For best function, keep the PIR lens and the solar panel clear. Use a damp cloth to wipe them. Do not use benzene, alcohol or paint thinner. !
- ! Do not mount where it can fall and injure others. !

Note:

For outdoor use only. Your pets may not be deterred by this product as they see your home as their home and territory.

HOW TO INSTALL:

1. Determine the location you want to place your Solar Animal Chaser.
 - Mounting locations are preferably at 5 to 8 ft in height, in view of the protected area, out of reach of children and placed where it can not fall and injure others.
2. Using a pencil, mark the center of where you would like the screw to be placed and have a drill bit a little smaller than the closed end of the plastic anchor ready.
3. Using the drill bit, drill a hole through the center of your mark and about as deep as the anchor is long.
4. Using a hammer or rubber mallet, gently tap the anchor until it is flush with the wall.
5. Insert the screw and slowly rotate it into the anchor leaving about $\frac{1}{8}$ or $\frac{1}{4}$ of the screw out to hang the Solar Animal Chaser.

Note: Anchors are most notably used on drywall and plaster, for most other walls it is not needed.

HOW TO USE:

The P7815 Solar Animal Chaser has a three position switch which is located on the bottom of the unit housing.

1. ON1 – When the motion sensor is triggered, the unit will produce a high pitched ultrasonic frequency in conjunction with a bright strobe light to ward away unwanted animals for 20 seconds.
2. OFF – Unit is off and the sensors will not be triggered.
3. ON2 – When the motion sensor is triggered, the unit will produce a high pitched ultrasonic frequency to ward away unwanted animals for 20 seconds

Specifications:

Model	P7815
Area Covered	up to 500 ft ² at an angle of 110° within a 23 ft distance
Strobe Light	2 Super bright LEDs
Audio Frequency	23 kHz
Solar Panel	4.8V 50mA
Battery	1 x LiFe 3.2V 500mAh
Weight	7.5oz (215g)
Dimensions	5.25 x 3.875 x 4.375 (H x W x D)

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION
TECHNICAL SUPPORT
Tel: 212-741-7289
Fax: 212-741-2288

Email: techsupport@p3international.com

Rev0613