

Operating Manual

P0260

Sol-Mate Window Thermometer

Thank you for purchasing the P0260 Sol-Mate Window Thermometer. This window thermometer is solar powered and can be placed either on the inside or outside of your window/glass door via a removable suction cup. This unit will provide you with years of service if cared for properly. Please read these operating instructions thoroughly before use.

How to Use:

- **Assembly**

1. Moisten suction cup before attaching to the window or glass door for a secure seal. Do not attach the suction cup to painted or other textured surfaces. The unit may fall and damage may occur.
2. To use outdoors, place the suction cup on the front of the unit so that the display is visible through the window.
3. To use indoors, place the suction cup on the back of the unit so the display is visible when the unit is attached to the window.
4. To reverse the suction cup, slide it down and remove from the unit. Affix it on the other side by sliding the suction cup mounting post into the slot and sliding upward.

- **Set Up**

1. Press the ON button to turn your thermometer on. By default the temperature display will be in Celsius, if you wish to change it to Fahrenheit press the ON button once more.
2. To reset your unit, press the Reset button.
3. To turn off your unit, press and hold the ON button for 5 seconds or until unit turns off.

- **Description**

1. This solar powered Window Thermometer has a temperature range from -13°F to 139°F (-25°C to 59.5°C) that displays in large LCD digits.
2. The Maximum and Minimum temperature during the last 24 hours will be recorded and displayed on the screen.
3. The temperature is updated every 8 seconds and displayed for your viewing.
4. The Temperature Trend feature displays via arrow on the display whether the temperature has dropped or risen from the original temperature read.

- **Note**

1. The unit will display temperature where it is located. (e.g. Indoors = indoor temperature). The local solar (sun) may affect temperature readings if left in direct sunlight for too long.
2. In order to recharge the internal battery the solar panel must be exposed to direct sunlight.

- **Warning**

1. **DO NOT use outside of a window where it may fall on pedestrians below. Injury may result.**
2. **Choking Hazard:** Keep small parts away from children, harmful if swallowed.
3. **DO NOT** tamper with the temperature sensor on the bottom of the unit.
4. Battery is not user replaceable.

Specifications:

Model:	P0260
Power Supply:	Solar Power
Built-in Battery:	1.5V Battery
Temperature Range:	-13°F to 139°F (-25°C to 59.5°C)
Dimensions:	3 3/8" x 1 3/4" x 1" (85x41x19 mm)
Weight:	1.5 oz.
Contents of Box:	Sol-Mate Window Thermometer unit and removable suction cup

*Specifications subject to change without notice.

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION
TECHNICAL SUPPORT
Tel: 212-741-7289
Fax: 212-741-2288

Email: techsupport@p3international.com

Rev. 0711