

P7885 LED Bug Trapper II

Traps and exterminates flying nuisances quietly, effectively, and hygienically!

The **LED Bug Trapper II** utilizes a specially made UV LED beam and a high efficiency fan to trap and dehydrate flying nuisances quietly, effectively, and hygienically. The built-in UV LED light effectively attracts mosquitoes to get close to the device. When they approach near light source, the flux of the air flow generated by the high efficiency fan will draw them into the compartment and trap them in the collection container. A patented uniquely designed funnel-shaped screen hinders the trapped mosquitoes from flying out even when the device is turned off.

The built-in intelligent control system offers three modes of operation:

OFF mode (power off)

AUTO mode (device automatically turns on at dusk and night; off during the daytime)

ON mode (power on for operating full time)

There is no maintenance or refill required -- just clean the captured insects from the collection container when necessary. The **LED Bug Trapper II** helps to create a mosquito free living space for you by using less than only 5 watts of power. *Flying insects affected: mosquitoes, black flies, no-see-ums, biting midges, , ..etc.*

APPLICATIONS:

- Apartments, houses, supermarkets, basements, garages, restaurants, and any indoor areas
- Patios, porches
- Any place with accessible electricity. Use only a covered weatherproof outdoor receptacle in outdoor applications.

OPERATING INSTRUCTIONS:

Please plug the device to a power outlet with the supplied AC adaptor. Use only a covered weatherproof outdoor receptacle in outdoor applications. Adjust the switch to select the desired mode of operation.

OFF mode (power off)

AUTO mode (device automatically turns on at dusk and night; off during the daytime)

ON mode (power on for operating full time)

While the flying insects trapped are dehydrated and accumulated to a point where airflow is impacted, it is recommended to clean the collection container by conducting the following steps.

1. Turn the device to mode OFF, then un-plug the AC Adaptor from the outlet.
2. Hold the main unit with one hand and detach the collection container from the main unit by twisting the bottom portion of the collection container counter-clockwise.
3. Clean the collection container and wash it with a brush if necessary.
4. Dry the collection container and replace it to the main unit properly by holding the main unit by the center portion and turn the bottom collection container clockwise to lock it back in place.
5. Re-plug the device to a power outlet with supplied AC adaptor, and then select the operation mode.

HOW TO OPEN/LOCK THE COLLECTION CONTAINER:

Twist the container counter-clockwise to open.

Twist the container clockwise to lock.

PLEASE NOTE

- Turn off and un-plug the device when it won't be used for a long time.
- Turn off the device when cleaning the collection container.
- Do not immerse the device in water or any other liquid.
- Do not tamper with the device's internal components.
- When necessary, use a damp cloth to gently wipe the dust off.
- During the winter time store the device indoors only.

SPECIFICATIONS:


Dimensions: 11" (H) x 6.3" (Ø)

Weight: approx. 16.25 oz. (main unit only)

Power supply: Switching power supply, 100-240VAC, 60/50Hz; 12VDC 500mA

Power consumption: 5W

Life span of UV LED and fan: up to 50,000 hours



P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your product, or if your product requires service please contact:

P3 INTERNATIONAL CORPORATION

TECHNICAL SUPPORT

Tel: 212-741-7289

Fax: 212-741-2288

Email: techsupport@p3international.com

Rev 1213